


MB982SPR-2S Firmware Update Instruction

1. Download latest RAID manager software for PC or Mac
Download link for PC: http://www.icydock.com/download/JMicronHWRaidMgr_v0.09.64.zip
Download link for Mac: http://www.icydock.com/download/JMicron_Mac_v0.09.58.zip
2. Install the new RAID software manager, and turn off the computer.
3. The system should be off at this point, install only one drive in the top bay of the MB982SPR-2S and reconnect the MB982SPR-2S to PC / Mac and turn on the computer.



4. Open the RAID manager software and wait until software sees the drive (it could takes couple minutes)








5. Once the software sees the drive, download the firmware version 0957 from following link:
http://www.icydock.com/goods_downloads.php?osid=32&softwareid=91&id=121
6. Unzip the file, and it will have a .bin file. Drag the bin file to the desktop or any folder you prefer, make note of its location so you can find it easily.



7. Make sure to close all other applications, and only leave the RAID manager software open.
8. In the RAID manager software, click the advanced mode, then click browse and select the .bin file from the desktop / folder and click update to update the firmware. (DO NOT TURN OFF THE POWER OR UNPLUG THE CONVERTER UNTIL THE UPDATE HAS COMPLETED)







9. Restart the system after the update, done.

